

INSTALLATION

Place foundation base in appropriate position on the grave space and in line. Mark around the base with a spade, move base and remove turf/soil to the correct depth and making sure it is level.

If fixing on a pre-poured beam/raft drill the correct hole in the correct place to correspond with the hole in your memorial base/foundation base. If a sub-base is required drive the anchor through the top of the foundation base making sure the washer is set to the depth required to take the memorial base.

1. If fixing memorial separately.

Place memorial base over the anchor and cement down. Using two 16mm x 6 inch dowels to cement memorial head to memorial base.

2. If fixing a memorial that has a bolting system head to base.

Make sure the D-Washer is adjusted to the correct thickness of memorial base. Lower the memorial over the anchor locating it in the bottom of the memorial base, using skids to offer it up into place. If a sub-base is required then the anchor should go through the top of the sub-base, and into the foundation base making sure they are both in line with each other.



1



2



3